



XN4-V2

Digitally controlled remote strain gauge amplifier

SN: X#######

Texense sensors are designed for data logging. Should the users want to include this sensor in a closed loop system, they must undertake total responsibility from doing so.

doina so.				
	Measuremen	t features		
Bridge gauge i	impedance ⁽¹⁾	350 to 1000	Ω	
Max	350Ω gauge	2		
recommended	1000Ω gauge	3.5	mV	
unbalance Offset drift with	3 3	<10	mV	
Gain drift with	<u> </u>	<0.2	%	
Bridge supp		5	V V	
Bridge supp	Analog o	J	٧	
Output		0 to 5	V	
Filte		1 pole filte	er ·	
Cut-off	Default	90		
frequency at -3dB	On request	Up to 9000	Hz	
Digital communication The digital wire Tx/Rx enables to set the following parameters				
Offset		0 to 5	V	
Gain		71 to 1270	-	
Gain compensation		-2000 to 2000	ppm/°C	
	Electrical fo	eatures		
Supply vo	oltage ⁽²⁾	5.5 to 16	V	
Supply current (amplifier alone)		3.5	mA	
Output im		100	Ω	
	Mechanical	features		
Dimensions		14 x 10.5 x 3.6	mm	
Material		PCB + Epoxy + stainless steel		
Weight		1	g	
	Environi	ment		
Accuracy te	mperature	-20 to +125	°C	
Operating te	mperature	-40 to +125	°C	
Storage ten	nperature	-40 to +125	°C	
Vibratio	n test	20 Gpp 5'		
Sho	ck	500	G	

(1)	For 120Ω	gauge,	please	consider	XN4-E	reference.
-----	-----------------	--------	--------	----------	-------	------------

⁽²⁾ For higher supply voltage, please consider XN4-E reference.

Date	Operator
Customer	
Order	
Product Ref	XN4-V2-##
SW version	V1.04

Readings (on a dummy gauge bridge)		
Output at 0mV input	Output at 10mV input	
V	V	

Software setup			
Offset	2.5	V	
Gain	200	V/V-	
Gain compensation	-340	ppm/°C	














Mechanical drawing





Wiring


There is no need for any balco, nickel, or manganin wires. There is no need for zero or sensitivity adjustment or compensation. The compensation is done on XN4 side.



Note: Texense also provides half bridge and quarter bridge versions. For complete information, contact us at info@texense.com

Remote application

In case the gauge bridge is remote from the XN4 amplifier, it is possible to use an external temperature probe close to the gauges to compensate the gauge temperature. The temperature probe is fitted close to the gauges to insure proper compensation. Only use $15k\Omega$ NTC Thermistor ($15k\Omega$ at 25° C, Beta = 4000). The external probe is automatically detected if connected and will be considered instead of internal one.









Bandwidth capacitor

The bandwidth can be specified at ordering (see § ordering information) or can be modified by adjusting the bandwidth capacitor. The capacitor value is defined by the formula: $C = \frac{1}{2\pi Fc \times 18000}$. The footprint is 0603, we recommend to use X7R ceramic capacitor.

Examples of capacitor values:

Capacitor	Cut-off frequency -3dB	
220nF	40Hz	
100nF	90Hz (Default)	
47nF	190Hz	
1nF	9kHz	

Digital offset temperature compensation

To compensate the offset drift, a self-learning procedure is available. This procedure involves to apply a specified temperature ramp in an oven and can be started thanks to the digital communication. See XN4 operating manual for complete information.

Digital gain temperature compensation

To compensate the sensitivity drift, we recommended to use the following parameters:

Material of strain gauged part	Usual coefficient (%/°C)	ppm/°C
Steel (default)	-0.033	-340
Titanium	-0.050	-500
Aluminum	-0.059	-590
No compensation (if XN4 is used with a compensated gauge bridge)	0	0

Digital communication

Drivers

It is necessary to download a VCP driver (Virtual Com Port) FTR232R to convert the USB port in Serial COM Port at the following address: https://ftdichip.com/drivers/vcp-drivers/. See information at https://ftdichip.com/document/installation-guides/.

Software

Use HyperTerminal (for Windows): www.hilgraeve.com/httpe/download.html or Teraterm: https://tera-term.en.softonic.com/ or any other COM port management software.

Settings

38400 bauds, 8 bits data, no parity, 1 bit stop, no flow control, recommended font Courrier New.

See XN4 operating manual for complete information.

Ordering information

