Attitude & Heading Reference System AHRS-II-P




A PHASIHO



AHRS-II-P Datasheet Rev. 1.9

The **Inertial Labs Attitude and Heading Reference Systems, AHRS-II** is the next generation of enhanced, highperformance strapdown systems that determines absolute orientation (**Heading, Pitch and Roll**) for any device on which it is mounted. Orientation is determined with high accuracy for both motionless and dynamic applications.



The Inertial Labs AHRS-II-P utilizes Tactical-grade IMU: 3-axes each of precision accelerometers & gyroscopes and Ultra High precision, gyro-compensated, embedded Fluxgate Compass to provide accurate Heading/Yaw, Pitch and Roll of the device under measure.

Integration of gyroscopes' output provides high frequency, real-time measurement of the device rotation about all three rotational axes. Accelerometers and Fluxgate magnetometer measure absolute Pitch, Roll and magnetic Azimuth at AHRS initial alignment as well as providing ongoing corrections to gyroscopes during operation.

KEY FEATURES AND FUNCTIONALITY

- State-of-the-art Kalman Filter based algorithms for different dynamic motions of UAV, Aircrafts, Helicopters, Vessels, Ships, ROV, UUV, Robots, UGV, AGV, Gimbals and Antennas
- Highly accurate, sensitive, and temperature stable Fluxgate magnetometers (in-house technology)
- Input from External GNSS Receiver;
- 0.6 deg Gyro-Stabilized Heading and 0.08 deg Pitch & Roll Dynamic Accuracy over operational temperature range
- 1 deg/hr gyroscopes Bias in-run stability
- 5 µg accelerometers Bias in-run stability
- Suitable for Primary Attitude Reference and as Motion Control System for marine applications
- Embedded 2D and 3D magnetic calibration on hard and soft iron
- RS-232, RS-422, USB and CAN 2.0 interfaces
- Full temperature calibration of all sensing elements
- Up to 200 Hz data update rate (AHRS) and 2000 Hz data rate (IMU)
- Compact design. Environmentally sealed (IP67)

One of the key elements to the success of Inertial Labs AHRS-II is its use of **Inertial Labs 8mm Fluxgate Magnetometers,** which have distinct advantages over commonly used magneto-inductive or magneto-resistive magnetometers. In operation over time and temperature fluxgate magnetometers have superior stability and repeatability. In terms of sensitivity, fluxgate magnetometers provide up to two orders of magnitude increased sensitivity.



In addition to the performance advantages, unlike the chip-level magnetometer technology, fluxgate magnetometer technology has been depended on for over 70 years to provide an accurate reference to North. It remains the most reliable magnetic sensor technology for determining an object's heading.

AHRS-II-P key specifications summary


Parameter	Units	Tripp:
Status		In production (Since 2006)
Heading static accuracy	deg	0.3
Heading dynamic accuracy	deg	0.6 (gyro magnetic)
Heading dynamic accuracy	deg	0.1 (with GNSS input)
Pitch & Roll static accuracy	deg	0.05
Pitch & Roll dynamic accuracy	deg	0.08
Gyroscopes Bias in-run stability	deg/hr	1
Accelerometers Bias in-run stability	mg	0.005


AHRS-II-P Specifications


- Dava wakay	Unite	
Parameter	Units	AHRS-II-P
Status	Without GNSS	In production Euler angles; Quaternion; Relative Altitude; Accelerations; Angular rates;
Output signals	input With GNSS input	Magnetic field; Pressure; Delta Theta and Delta Velocity Horizontal & Vertical Positions (LAT, LONG); Heading, Pitch, Roll, Velocity, PPS time, IMU data (angular rates, accelerations)
Input signals	Input	External GNSS receiver, External magnetic compass
Update rate (AHRS data)	Hz	1 200 (user settable)
Update rate (IMU data)	112	2000 Hz
Start-up time	sec	< 1
Full Accuracy Data (Warm-up Time)	sec	10
Heading	Units	
Range	deg	0 to 360
Angular Resolution	deg	0.01
Static Accuracy Over Operational Temperature Range	deg	0.3
Dynamic Accuracy Over Operational Temperature Range	deg RMS	0.6
Pitch and Roll	Units	
Range: Pitch, Roll	deg	±90, ±180
Angular Resolution	deg	0.01
Static Accuracy in whole Temperature Range	deg	0.05
Dynamic Accuracy Over Operational Temperature Range	deg RMS	0.08
Relative altitude	Units	
Measurement range	meters	-600 to 9000
Resolution	meters	0.01
Relative accuracy	meters	<1
Gyroscopes	Units	
Measurement range	deg/sec	±450 / ±950
Bandwidth	Hz	200
Bias in-run stability (RMS, Allan Variance)	deg/hr	
Bias residual error over operational temperature range SF accuracy	deg/hr, RMS %	<35 0.3
Noise (Angular Random Walk)	 deg/√hr	<0.2
Noise (Aliguial Kalidolli Walk) Non-linearity	%	0.01
Axis misalignment	mrad	0.15
Accelerometers	Units	0.15
Measurement range	g	±8 / ±15
Bandwidth	Hz	200
Bias in-run stability (RMS, Allan Variance)	mg	0.005
Bias residual error in temperature range, RMS	mg	<0.5
SF accuracy	%	0.01
Noise (Velocity Random Walk)	m/s/√hr	0.015
Non-linearity	%	0.05
Axis misalignment	mrad	0.1 mrad
Magnetometers (Embedded Fluxgate Compass)	Units	
Measurement range	Gauss	±1.6
Bias in-run stability, RMS	nT	0.2
Noise density, PSD	nT√Hz	0.3
SF accuracy	%	0.02
Bandwidth	Hz	50
Pressure	Units	200 1100
Measurement range	hPa	300 - 1100
Bandwidth Resolution	Hz Pa	50
Bias in-run stability (RMS, Allan Variance)	Pa Pa	0.8
Noise density	Pa Pa/√Hz	1
Environment		
Operating temperature	deg C	-40 to +70
Storage temperature	deg C deg C	-50 to +85
MTBF (G _M @ +65deqC)	hours	100,000
Vibration & Shock	10015	MIL-STD-810G
EMC/EMI	1	MIL-STD-461
Electrical	Units	
Supply voltage	V DC	9 to 36
Power consumption	Watts	1.4
	-	RS-232, RS-422, CAN 2.0 and USB (with external converter)
Output Interface		
Output Interface Output data format	-	Binary, TSS-1, NMEA 0183 ASCII characters
	Units	Binary, TSS-1, NMEA 0183 ASCII characters
Output data format		Binary, TSS-1, NMEA 0183 ASCII characters 120 x 50 x 53

Inertial Labs Address: 39959 Catoctin Ridge Street, Paeonian Springs, VA 20129 U.S.A. Tel: +1 (703) 880-4222, Fax: +1 (703) 935-8377 Website: www.inertiallabs.com

Inertial Labs AHRS-II-P key performance







Inertial Labs Address: 39959 Catoctin Ridge Street, Paeonian Springs, VA 20129 U.S.A. Tel: +1 (703) 880-4222, Fax: +1 (703) 935-8377 Website: www.inertiallabs.com


4

AHRS-II-P

Datasheet Rev. 1.9

AHRS-II-P Datasheet Rev. 1.9

AHRS-II-P mechanical interface drawing



1. All dimensions are in millimeters.

2. All dimensions within this drawing are subject to change without notice. Customers should obtain final drawings before designing any interface hardware.

<u>Connector type</u>: Binder Series 723. Male receptacle, 24 pin, shielded, rear-mounting